




*Indicates parts not visible on drawing.





Figure 3



Part No.	Description	Qty.	Part No.	Description	Qty.
H891W-D2Q-05	Gauge 60# 1 1/2" Dia.	1	H891W-D2Q-22	Pilot Regulator Valve Assembly	1
-D2Q-06	Gasket Kit	1	-D2Q-23	Spring	1
-D2Q-07	Lid	1	-D2Q-24	Spring Expander	1
-D2Q-08	Nut 1/4 NPS	1	-D2Q-25	Body	1
-D2Q-09	Fluid Tube	1	-D2Q-26	Air Adjusting Valve	1
-D2Q-10	Regulator Protector Assembly	1	-D2Q-27	O' Ring	1
-D2Q-11	Gasket Kit	1	-D2Q-28	Adjusting Screw	1
-D2Q-12	Gasket Kit	1	-D2Q-29	Spring Kit	1
-D2Q-13	Cup	1	-D2Q-30	Valve & Disc Assembly	1
-D2Q-14	Air Regulator Assembly	1	-D2Q-31	Coupling 1/4 NPS (M) X 1/8 NPT (M)	1
-D2Q-15	Knob Assembly	1	-D2Q-32	Control Valve Assembly	1
-D2Q-16	Spring Depressor Button	1	-D2Q-33	Adapter-Loose Nut for DL-519	1
-D2Q-17	Spring	1	-D2Q-34	Union Body	1
-D2Q-18	Diaphragm Retaining Nut	1	-D2Q-35	Ball	1
-D2Q-19	Pilot Valve & Diaphragm Assembly-Lapped	1	-D2Q-36	Union Tail Piece for DL-520	1
-D2Q-20	Diaphragm Assembly	1	-D2Q-37	Nut	1
-D2Q-21	Valve Seat Holder	1	-D2Q-38	Spacer	2
			-D2Q-39	Screw	2