

# HIGH VOLUME LOW PRESSURE GRAVITY FEED TOUCH-UP SPRAY GUN

H828W/H.V.L.P.

## TECHNICAL DATA:

NOZZLE SIAE : ☐0.5MM ☐0.8MM ☐1.0MM ☐1.1MM

COLOR: ☐GREEN ☐RED ☐BLUE ☐NICKLE PLATED


CUP: ☐ 125 ml non-drip plastic cup

☐ 125 ml aluminum cup

Regulator : ☐



☐



Air Consumption: MAX 43PSI (3BAR)

## OPERATION:

### A. Starting :

- Use spanner to tight the nozzle.
- Check for correct tightening of stuffing box to avoid any air leakage.
- Air hose should be blow out before fitting with the air connection.
- Before using this gun, Please make sure that it is carefully flushed w/solvent.

### B. Adjustment of Spray Width

Rotate the stepless adjuster to adjust spray width. The spray pattern can be altered from flat to round spray as required.

### C. Air Quantity Control

Adjust the stepless air micrometer to set the air to material ratio.

### D. Exchange of Nozzle Set

Make sure that the complete nozzle set is exchanged when changing to another nozzle. A set comprises of air cap, paint nozzle and paint needle.

### E. Tensioning of Packing Screw on Needle Seal

The needle seal is effected by a teflon seal and a needle packing with self-tensioning compression spring.

To Change the packing during general overhaul, please use the socket spanner.

### F. Cleaning and Gun Care

- Flush gun thoroughly with solvent.
- Clean air nozzle with brush. Never place the whole gun to solvent.
- Clogged holes should never be cleaned with hard objects as the smallest amount of damage may badly influence the spray pattern.
- Packing must be slightly lubricated after cleanning of gun.

**\*\*WARNING : NEVER AIM SPRAY GUNS AT PEOPLE, SOLVENTS AND THINNERS CAN CAUSE INJURY**

